

OPTIMAL TEMPERATURES

	SAFE ZONES	ANGER ZONES
REFRIGERATOR	32°F-40°F	42°F +
FREEZER	-20°F-0°F	10°F +

Hang or stand thermometer in the fridge or freezer to help monitor food safe temperature zones. Keeping your appliances at the proper settings will help with energy usage and food spoilage.

CLEANING AND CARE:

Handwash only. Do not immerse in water or put in dishwasher.

LIFETIME WARRANTY



MODEL 5924
©2017 Taylor Precision Products
Seattle, WA 98134

For warranty information please call 1,866,843,3905
or visit us online at: SHOPTAYLORUSA.COM



5924_01.30.17

Made in China

Place
Sticker
Here

